Meaningful Innovation.

INSTRUCTION MANUAL

LED BACKLIT SURFACE MOUNTED PANEL





02 YEAR WARRANTY*

TECHNICAL DATA

MODEL	SKU	SHAPE	WATTS	LUMENS	BEAM ANGLE	IP RATING	CRI	BODY TYPE	TOTAL CURRENT	INPUT VOLTAGE	LIFE SPAN [HOURS]	ON/OFF CYCLE [TIMES]	DIMENSION (LxWxH)
VT-60006	7870 10492 7871 10493 7872 10494	ROUND	6W	660 Lm	120°	IP20	>80	PLASTIC	36mA	AC:220-240 50/60Hz	20000	>15000	Ø121.2x30.6mm
		SQUARE											120.8x120.8x30.7mm
VT-60012	7873 10495 7874 10496 7875 10497	ROUND	12W	1200 Lm	120°	IP20	>80	PLASTIC	71mA	AC:220-240 50/60Hz	20000	>15000	Ø167.4x30.7mm
		SQUARE											167.3x167.3x30.7mm
VT-60018	7876 10498 7877 10499 7878 10500	ROUND	18W	1850 Lm	120°	IP20	>80	PLASTIC	103mA	AC:220-240 50/60Hz	20000	>15000	Ø215.6x30.8mm
		SQUARE		1980 Lm									214x214x31mm
VT-60024	7879 10514 7880 23023 7881 10516	ROUND	24W	2500 Lm	120°	IP20	>80	PLASTIC	160mA	AC:220-240 50/60Hz	20000	>15000	Ø288.6x31.2mm
		SQUARE		2640 Lm									287x287x30.7mm

This product contains a light source of energy efficiency class <F/E>', where <F/E> shall be replaced by the energy efficiency class of the contained light source.

INTRODUCTION & WARRANTY

Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 2 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. The products are suitable for 10-12 Hours Daily operation. Usage of product for 24 Hours a day would void the warranty. This product is warranted for manufacturing defects only.

WARNING


- Please make sure to turn off the power before starting the installation.
- Installation must be performed by a certified person.
- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- Method of attachment of the cable or cord such that any replacement can only be made by the manufacturer, his service agent or similar qualifed person.
- For Indoor use only.

MULTI-LANGUAGE MANUAL QR CODE

Please scan the QR code to access the manual in multiple languages.

This marking indicates that this product should not be disposed of with other household wastes.

Caution, risk of electric shock.



Replaceable (LED only) light source by a professional



ATTENTION!

Do not look directly at LED light beam. Product can only be supplied by rated voltage or voltage within the range provided. It's forbidden to use the product with damaged protective cover. Product must not be used in unfavorable conditions, e.g. dust, water, moisture, vibrations, explosive air atmosphere, fumes, or chemical fumes, etc. In the area of strong electromagnetic interference, the functioning of the product may be disrupted.


USAGE GUIDELINES/MAINTENANCE

Any maintenance work must be performed when the power supply is cut off and the product has cooled down. Clean only with soft and dry cloths. Do not use chemical detergents. Do not cover the product. Ensure free air access. Product may heat up to a higher temperature.


MOUNTING

Read the manual before mounting. Mounting should be performed by a qualified electrician. Exercise caution. Product has a protective contact /terminal. Failure to connect the protective lead may lead to electric shock. Mounting diagram: see pictures. Check for proper mechanical fastening and connection to electrical power prior to first use.


WIRING DIAGRAM




SURFACE PANEL INSTALLATION DIAGRAM




1.Switch OFF the power before starting the installation




2.Confirm the installation position of the bracket




3.Drill a hole.




4.Plug in expansion bolt.




5.Fix the bracket (Included) on the ceiling with screws.




6. Connect the wiring as per wiring diagram.



7.Fix the panel onto the bracket




8.Fix the light and bracket with screws.




9.Switch ON the power and test the light.

DISASSEMBLY DIAGRAM


(For Market surveillance team only)




1.Power off, tap the central area of the diffusion plate with a pointed tool, and take out the cracked diffusion plate




2.Remove the power wire from the plug terminal




3.If there is no hot melt column in the lamp body or the hot melt column is not hot melt,this step will be adjusted without treatment.If the hot-melt column has been fused to fix the aluminum substrate,cut the hot-melt part of the hot-melt point with diagonal pliers.



4.Press the buckle outwards, remove the aluminum substrate pressing strip from the bayonet, and remove the pressing strip. This step is only required for 24W panel light, other items are not required.



5.Press the buckle outwards, remove the aluminum substrate from the buckle, and remove the light source board.



6.Take out two-cord cable (wire diameter 18-22AWG) and insert it into the plug-in terminal. Connect the external power supply for testing.

Note

- Light source removal will void the warranty.
- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

V-TAC WEST EUROPE LTD. IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT, PLEASE REACH OUT TO US AT: SUPPORT@V-TAC.EU FOR MORE PRODUCTS RANGE, INQUIRY PLEASE CONTACT OUR DISTRIBUTOR OR NEAREST DEALERS. V-TAC WEST EUROPE LTD. GROUND FLOOR, 71 LOWER BAGGOT STREET, DUBLIN 02, IRELAND DO2 P593

V-TAC UK LTD. IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT PLEASE REACH OUT TO US AT SUPPORT@VTACEXPORTS.COM V-TAC, 5A TUNGSTEN PARK, DOWNS ROAD, WITNEY, OXFORDSHIRE, OX29 0AX