Meaningful Innovation.

INSTRUCTION MANUAL

3 PLUG-IN UK SOCKETS WITH REMOTE CONTROL



TECHNOICAL DATA	
SKU	10186
VOLTAGE	230V~/50Hz
MAX. POWER RATING	2900W max.
REMOTE FREQUENCY	433.92MHz
REMOTE RANGE	20 Metres
BATTERY TYPE	Button Cell 2x1.5V LR44 (Battery not included)

02 YEAR WARRANTY*

INTRODUCTION & WARRANTY

Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 2 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product.This product is warranted for manufacturing defects only.

WARNING

1. Please make sure to turn off the power before starting the installation.
2. Plug in fully to the wall outlet while using
3. Do not insert a conductor or other tools to the socket hole
4. Do not use in bathroom and other damp locations
5. Please keep the device out of the reach of children to avoid danger

This marking indicates that this product should not be disposed of with other household wastes.

Caution, risk of electric shock.

MULTI-LANGUAGE MANUAL QR CODE

Please scan the QR code to access the manual in multiple languages.

IMPORTANT SAFEGUARDS

When using any electrical appliance, in order to reduce the risk of fire, electric shock and/or injury to persons, basic safety precautions should always be followed, including:

- The appliance is for household and indoor use only.
- Before plugging in, check that the voltage on the rating label is the same as the mains supply.
- To protect against electric shock, do not immerse any part of the product in water or other liquid. This socket is intended for use by competent adults only and children should be supervised at all times.
- Do not use the socket for other than its intended use.
- This socket can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- Don't use this socket in the immediate surroundings of a bath, a shower or a swimming pool.
- In case of malfunction, do not try to repair the socket yourself, it may result in a fire hazard or electric shock

DO NOT EXCEED MAXIMUM 2900W

Place the LR44 batteries (Battery not included) into the compartment in the back of the Remote Control, please insert as shown in the back of the compartment to ensure the polarity is correct.



PROGRAMMING INSTRUCTIONS

- Plug the Remote Sockets(s) into the wall socket(s) and switch on the mains supply, the red LED will flash every second.
- If the LED is not flashing press & hold the manual ON/OFF button for 5 seconds until it flashes
- Press any ON switch on the Remote Control for approximately 2 seconds and the Remote Socket(s) will learn the code.
- The LED will stop flashing top confirm the code has been accepted.
- Any number of Remote Sockets can be programmed to one Remote Control ON button to create multiple switching.
- To programme other Remote Sockets on different Remote Control ON buttons repeat the previous steps.
- If the mains supply is turned off the Remote Sockets will lose their code and it will be necessary to re-programme.

OPERATION

- Plug your appliance(s) into the Remote Socket(s)
- Press the programmed ON or OFF button on the Remote Control to control the Remote Socket.
- The Remote Sockets can also be operated manually using its ON/OFF Button

TROUBLE SHOOTING

If a Remote Socket does not react to the Remote Control please check the following:

- Low battery in the Remote Control
- Distance too large between the remote control and the receiver (ensure the range distance is no more than 20 clear Metres) and free from obstacle that may reduce the distance.
- If programming has not been successful, turn the power off and back on then follow the programming steps above.

HOW TO DECODE

- Press the manual ON/OFF button for 5 seconds until the red LED flashes once per second to confirm de-coding is successful.
- Press the ALL OFF switch on the Remote Control for more than 3 seconds, the LED flashes once per second to confirm decoding is successful.

RoHS CE 20 PAP UK CA

IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT PLEASE REACH OUT TO US AT SUPPORT@VTACEXPORTS.COM
V-TAC HOUSE, KELPATRICK ROAD, SLOUGH, BERKSHIRE, SL1 6BW, UK.